

561-V

SCOOPEXL vertical fastener

Code: 561-V



561-V

FERNO
When It's Critical®



Designed especially for fastening the SCOOPExL stretcher to a wall in vertical position.

MAIN FEATURES

- 561-V is designed to fasten the stretcher in vertical position inside the ambulance.
- The fastener includes two mounting brackets, upper and lower. The lower bracket is equipped with two hooks and the upper bracket is equipped with an handle for locking and unlocking the stretcher by a simple rotation while pressing the red button.
- Tested in accordance with EN 1789

Description

Fastener for SCOOPExL, vertical position

Code

561-V